

How to Enable Charging With Your RFID Card

Applies only to EVR30-R2C


1. Enable charging.

TAP your RFID card to the front of the charger over the image of the RFID. The POWER light will flash green quickly when the RFID card has enabled the unit to charge.




2. Start charging.

Press and hold the black button on the top of the charge plug and insert it into the inlet on your car. Charging starts automatically. The CHARGE light will flash green.



3. How to stop and restart.

To stop charging, press black button on top of charge plug to remove plug. To restart charging, tap your RFID card, press black button and reinsert.



4. After charging is complete.

NOTE: When charging is complete, loop charging cable over station to prevent tripping hazard.



NOTE: If the charging station is not being used for an extended period of time, it should be turned off.

**RFID cards need to be requested from the parish administration.
Please contact the parish office at 919-942-1040.**